






RETIFICADOR DE SOLDA ESAB LHJ 750



(62) 3250-0700



N/A LATERAL ESQUERDA LEFT SIDE TABLERO IZQUIERDO
 N/A LAMPA COVER TAPA
 MA2446 OLHAL LIFTING HOOKS CARRILHÃO
 MA2262 PUXADOR HANDLE MANIVELA
 N/A LATERAL DIREITA RIGHT SIDE TABLERO DERECHO
 MA2216 SUPORTE GIRATORIO SUPPORT SUPPORTO GIRATORIO
 N/A CARRINHO COMPLETO TROLLEY CARRILHO

MA1418 LAMPADA PILOTO PILOT LAMP LAMPARA PILOTO
 MA22151 VISOR WINDOW VISOR
 N/A PAINEL FRONTAL FRONT PANEL TABLERO FRONTAL
 MA2071 MANIVELA CRANK MANIVELA
 MA0412 CHAVE MA1534 DISJUNTOR CHAVE LIGAV/DES LIGA ON/OFF SWITCH LLAVE ENCENDIDO/APAGADO
 MA21115 TOMADA OUTLET ENCHUFE
 MA2173 CONJUNTO TERMINAL OUTPUT TERMINAL

MA1820 HELICE PROPELLER
 N/A PAINEL TRASEIRO REAR PANEL TABLERO TRASEIRO
 AC0424 CABO DE ALIMENTAÇÃO INPUT CABLE CABLE

MA0143 VOLTAMP DIGITAL DIGITAL VOLT/AMP
 MA20114 ESCALA SCALE
 N/A FREIO DO FUSO BRAKE FRENO DEL HUSO
 MA1720 TRANSFORMADOR TRANSFORMER
 MA2033 MOLA COIL MUELLE
 N/A GUIA DIREITA RIGHT GUIDE GUIA DERECHA
 N/A GUIA ESQUERDA LEFT GUIDE GUIA IZQUIERDA
 MA1811 SUPORTE DO VENTILADOR FAN SUPPORT SOPORTE DEL VENTILADOR
 MA1819 MOTOR DO VENTILADOR FAN ENGINE MOTOR DEL VENTILADOR
 MA1931 RODA 12" WHEEL 12" RUEDA 12"
 TRANSFORMADOR COMPLETO TRANSFORMER
 MA1935 RODA 12" WHEEL 12" RUEDA 12"

MA2104 BLOCO DE LIGAÇÃO (IN) CONNECTION (IN) BLOQUEO DE CONEXION (IN)
 N/A NÚCLEO MÓVEL MOBILE CORE NÚCLEO MOVIL
 N/A GUIA ESQUERDA LEFT GUIDE GUIA IZQUIERDA
 MA21107 FUSO SCREW HUSO
 N/A PORCA DO NÚCLEO CORE NUT TUERCA DEL NÚCLEO
 MA20104 RAIL RAIL I
 MA22107 CHAVES BARS CHAVES
 MA0324 PONTES RETIFICADORAS RECTIFIER BRIDGES PUNTES RECTIFICADORES

N/A BOBINA B COIL B
 MA1154 BOBINA C COIL C
 MA1151 BOBINA A COIL A
 TRANSFORMADOR VISTA FRONTAL TRANSFORMER FRONT VIEW